



Before beginning any installation, review Pentek Intellidrive™ Owner's Manual PN957 for complete instructions and warnings. This guide neither supplements nor replaces the Owner's Manual.

What's Included



Bottom Screen (Qty. 1)



Side Screen (Qty. 2)

NOTICE: Screens should occasionally be checked and cleaned of debris to ensure proper drive operation. As the screens become dirty or blocked, the drive may de-rate itself to manage internal drive temperature. If the drive de-rates, it will slow down the pump which may reduce water output.

Step 1 – Remove cover from the drive.



A. Shut off the power to the drive. [Wait 5 minutes to allow capacitors to de-energize.]



B. Separate cover and back plate.





C. Verify there is a gap between cover and back plate.



D. Pull out bottom of cover and remove.

Step 2 - Install magnetic screens on both sides and bottom as shown:



To ensure screens are effective, insert caps, cord grips, or conduit connectors in all open wiring holes to close any gaps.

Step 3 – Replace drive cover and restore power to the drive



Hook the cover onto the backplate, lower it into place, and then push the cover back to close the gap.